

Notebooks, Netbooks and UMPCs

Green Text with Light Green Background indicates the adapter tip is included with product.

Red Text with Clear Background indicates the adapter tip is sold separately.

N/A indicates that the adapter is not available or the product is not compatible.

Acer Aspire One

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Aspire One A110L, A110X	PA-N12	PA-N12	PA-N12	
Aspire One A150, A150L, A150X, A150X-3G	PA-N12	PA-N12	PA-N12	
Aspire One D150	PA-N12	PA-N12	PA-N12	

Acer Aspire

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
2000, 2010, 2020, 2200 Series	PA-L5F	PA-L5F	PA-L5F	
3000, 3500, 3600, 3610, 3624, 3630, 3680 Series	PA-L47	PA-L47	PA-L47	
3020, 3025, 3040, 3620, 3690 Series	PA-L5F	PA-L5F	PA-L5F	
5000, 5020, 5030, 5040, 5100, 5110, 5500, 5600, 5610, 5630, 5680, 5920 Series	PA-L5F	PA-L5F	PA-L5F	
5010, 5012, 5014, 9800, 9805, 9810 Series	PA-L47	PA-L47	PA-L47	
7000, 7100 Series	PA-L5F	PA-L5F	PA-L5F	
9100, 9300, 9410, 9420, 9500 Series	PA-L5F	PA-L5F	PA-L5F	

Acer Ferrari

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
1000, 1004, 3000, 3200, 3400, 4000, 5000 Series	PA-L5F	PA-L5F	PA-L5F	

Acer Timeline

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
AS3810T Series	PA-N12	PA-N12	PA-N12	

Acer TravelMate

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
A550, A551, Alpha 550, Alpha 551 Series	PA-L5D	PA-L5D	PA-L5D	
C100, C110, C200, C210, C300, C310 Series	PA-L47	PA-L47	PA-L47	
200, 210, 212, 213, 220, 225, 230, 233, 260, 270, 272, 273, 280, 283 Series	PA-L5D	PA-L5D	PA-L5D	
240, 243, 244, 250, 252, 253, 290, 291, 292, 293 Series	PA-L5F	PA-L5F	PA-L5F	
530, 531, 533, 534, 535, 536 Series	PA-L5D	PA-L5D	PA-L5D	
540, 541, 542, 543 Series	PA-L5F	PA-L5F	PA-L5F	
600, 603, 610, 611, 612, 613, 614, 620, 630, 631, 650, 653, 654, 660 Series	PA-L5D	PA-L5D	PA-L5D	
720, 722, 730, 732, 735, 739, 740, 800, 801, 802, 803, 804 Series	PA-L5D	PA-L5D	PA-L5D	
2000, 2100, 2200, 2500, 2600, 2700 Series	PA-L5D	PA-L5D	PA-L5D	
2300, 2310, 2350, 2400, 2420, 2450, 2480 Series	PA-L5F	PA-L5F	PA-L5F	
3000, 3200, 3210, 3220, 3230, 3260 Series	PA-L47	PA-L47	PA-L47	
5100, 5110, 5300, 5600, 5610, 5612, 6000, 6100, 6410, 6460, 6592 Series	PA-L5F	PA-L5F	PA-L5F	
7000, 7100, 7300, 8000, 8100, 8200, 8204, 8205, 8210, 8215, 8216 Series	PA-L5F	PA-L5F	PA-L5F	

Apple

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
PowerBook: 1400, 2400, 3400 Series	PA-N03	PA-N03	PA-N03 & MP3400-40	
PowerBook: G3 Series	PA-N03	PA-N03	PA-N03 & MP3400-40	
PowerBook G4, iBook G4	n/a	n/a	n/a	Adapter not available.
MacBook, MacBook Pro	PA-MAG	PA-MAG	PA-MAG & MP3400-40	

ASUS Eee PC

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Eee Slate EP121 Tablet PC	PA-L30	PA-L30	PA-L30 & MP3400-40	
Eee PC 700, 900 Series	PA-L47	PA-L47	PA-L47	
Eee PC 1000HA, 1000HD Series	PA-L47	PA-L47	PA-L47	
Eee PC 1005, 1008, 1101, 1201 Series	PA-L23	PA-L23	PA-L23 & MP3400-40	

ASUS

Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
A6, A6JA, A6JC, A6K, A6KM, A6KT, A6R, A6V, A6VA, A6Vc, A6VM, A7S, A8, A8F Series	PA-L5F	PA-L5F	PA-L5F	
F3, F3P, F8, F9, F9F Series	PA-L5F	PA-L5F	PA-L5F	
G1 Series	PA-L5F	PA-L5F	PA-L5F	
G2, G2 P, G2 S, G60VX, G70, G71, G72 Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
M2000, M2000N, M6000N, M6700N, M6800N, M6B00N Series	PA-L5F	PA-L5F	PA-L5F	
M6N, M6V, M6VA, M9V, M50, M51, M70 Series	PA-L5F	PA-L5F	PA-L5F	
R1E, S6F, U3, USA, U5F, U6E, U6S Series	PA-L5F	PA-L5F	PA-L5F	
V1, V1J, V2, V6, VX2, VX3 Series	PA-L5F	PA-L5F	PA-L5F	
W3000, W3, W3N, W3V, W5A, W5Ae, W5F, W5V, W7, W7J, Z35L Series	PA-L5F	PA-L5F	PA-L5F	

Dell Adamo				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Adamo 13	PA-L5F	PA-L5F	PA-L5F	

Dell Alienware				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
M11x, M11x R2 Series	PA-N11	PA-N11	PA-N11	
M15x, M17x Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.

Dell Inspiron				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
14, 15, 17 Series	PA-N11	PA-N11	PA-N11	
1100 Series	PA-N07	PA-N07	PA-N07/MP3400-40	
1150, 1318, 1420 Series	PA-N11	PA-N11	PA-N11	
1501, 1505, 1520, 1521, 1525, 1526, 1545 Series	PA-N11	PA-N11	PA-N11	
1720, 1721 Series	PA-N11	PA-N11	PA-N11	
4000, 4100, 4150, 4200, 5000, 5100, 5150 Series	PA-N07	PA-N07	PA-N07/MP3400-40	
6000, 6400 Series	PA-N11	PA-N11	PA-N11	
7500, 8000, 8100, 8200 Series	PA-N07	PA-N07	PA-N07/MP3400-40	
8500, 8600, 9100, 9200, 9300, 9400 Series	PA-N11	PA-N11	PA-N11	
300m, 500m, 600m, 630m, 640m, 700m, 710m Series	PA-N11	PA-N11	PA-N11	
E1405, E1505, E1705 Series	PA-N11	PA-N11	PA-N11	
Mini 9, Mini 10, Mini 12	PA-N12	PA-N12	PA-N12	

Dell Latitude				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
13 Series	PA-N11	PA-N11	PA-N11	
2100, 2100n Series	PA-N11	PA-N11	PA-N11	
CP, Cpi, CPl, CS, CPx Series	PA-N07	PA-N07	PA-N07/MP3400-40	
D400, D410, D420, D430 Series	PA-N11	PA-N11	PA-N11	
D500, D505, D510, D520, D530, D531, D560 Series	PA-N11	PA-N11	PA-N11	
D600, D610, D620, D630, D631 Series	PA-N11	PA-N11	PA-N11	
D800, D810, D820, D830 Series	PA-N11	PA-N11	PA-N11	
E4200, E4300, E5400, E5500, E6400, E6500 Series	PA-N11	PA-N11	PA-N11	
XT, XT2 Series	PA-N11	PA-N11	PA-N11	
X1, X300 Series	PA-N11	PA-N11	PA-N11	
Z Series	PA-N11	PA-N11	PA-N11	

Dell Precision				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
M20 Series	PA-N11	PA-N11	PA-N11	
M60, M65, M70 Series	PA-N11	PA-N11	PA-N11	
M90 Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
M2300, M2400, M4300 Series	PA-N11	PA-N11	PA-N11	
M4400	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
M6300, M6500 Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.

Dell Studio				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Studio 13, 14z, 15, 1535, 1536, 1537, 1555, 1557 Series	PA-N11	PA-N11	PA-N11	
Studio XPS 13, Studio XPS 1340	PA-N11	PA-N11	PA-N11	
Studio XPS 16 Series	PA-N11	PA-N11	PA-N11	

Dell Vostro				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
A90, A840, A860 Series	PA-N11	PA-N11	PA-N11	
1000, 1220, 1310, 1320, 1400, 1500, 1510, 1520, 1700 Series	PA-N11	PA-N11	PA-N11	
2510, 3000, 3300, 3400, 3500 Series	PA-N11	PA-N11	PA-N11	
V13 Series	PA-N11	PA-N11	PA-N11	

Dell XPS				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
M140 Series	PA-N11	PA-N11	PA-N11	
M1210, M1330, M1530 Series	PA-N11	PA-N11	PA-N11	

Fujitsu LifeBook				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
A4170, A4177, A4178, A4187, A4190, A6010, A6020, A6025, A6030, A6110, A6120, A6210, A6210, A6220, A6230 Series	PA-L5F	PA-L5F	PA-L5F	
B2130, B2131, B2175, B2545, B2562, B2566, B2610, B2620, B2630 Series	PA-L65	PA-L65	PA-L65	
B3000, B3000D, B3010D, B3020, B3020D Series	PA-L65	PA-L65	PA-L65	
B6110D, B6210, B6220, B6230 Series	PA-L65	PA-L65	PA-L65	
C2010, C2110, C2111, C2210, C2310, C2320, C2330 Series	PA-L5F	PA-L5F	PA-L5F	
C-6581, C-6591, C-6611, C-6631, C-6651, C-7631, C-7651, C-7661 Series	PA-L65	PA-L65	PA-L65	
E6550, E6555, E6556, E6557, E6570, E6571, E6575, E6595 Series	PA-L65	PA-L65	PA-L65	
E6824, E6834, E6644, E6654, E6664, E6666, E7010, E7110 Series	PA-L5F	PA-L5F	PA-L5F	
E8010, E8010D, E8020, E8020D, E8110, E8210, E8310, E8410 Series	PA-L5F	PA-L5F	PA-L5F	
M2010 Series	PA-L5F	PA-L5F	PA-L5F	
N3000, N3010, N3511, N3520, N3530 Series	PA-L5F	PA-L5F	PA-L5F	
N5000, N5010, N6010, N6110, N6210, N6410, N6420 Series	PA-L5F	PA-L5F	PA-L5F	
P1000, P1032, P1035, P1120, P1510, P1510D, P1610, P1620, P1630 Series	PA-L65	PA-L65	PA-L65	
P5000, P5010, P5010D, P5020, P5020D, P7010, P7010D Series	PA-L65	PA-L65	PA-L65	
P7120, P7120D, P7230, P7230D, P7230P, P8010, P8020 Series	PA-L65	PA-L65	PA-L65	
Q2010 Series	PA-L65	PA-L65	PA-L65	
S2010, S2020, S2110 Series	PA-L65	PA-L65	PA-L65	
S2210 Series	PA-L5F	PA-L5F	PA-L5F	
S6010, S6110, S6120, S6120D, S6210, S6220, S6231, S6240 Series	PA-L65	PA-L65	PA-L65	
S6310, S6311, S6410, S6510, S6520 Series	PA-L5F	PA-L5F	PA-L5F	
S7000, S7000D, S7010, S7010D, S7020, S7020B, S7020D, S7020E, S7021, S7025, S7110, S7111, S7210, S7211, S7220 Series	PA-L5F	PA-L5F	PA-L5F	
T1010, T4010, T4010D, T4020, T4020D Series	PA-L5F	PA-L5F	PA-L5F	
T4210, T4215, T4220, T5010, T5010A, T5010W Series	PA-L5F	PA-L5F	PA-L5F	
U810, U820 Series	PA-L65	PA-L65	PA-L65	
V1010, V1020, V1030, V1040 Series	PA-L5F	PA-L5F	PA-L5F	

Fujitsu Stylistic				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
ST4110, ST4110P, ST4120, ST4120P, ST4121 Series	PA-L65	PA-L65	PA-L65	
ST5000, ST5000D, ST5010, ST5010D, ST5011, ST5011D, ST5020, ST5020D, ST5021, ST5021D, ST5022, ST5022D, ST5030, ST5030D, ST5031, ST5031D, ST5032, ST5032D, ST5111, ST5112, ST6012 Series	PA-L65	PA-L65	PA-L65	
T2010, T2020, T3010, T3010D Series	PA-L65	PA-L65	PA-L65	

Gateway				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
400, 400L, 400S, 400SD4, 400SP, 400VTX, 400X, 400XL, 450, 450E, 450RGH, 450ROG, 450S, 450SP, 450SX4, 450X, 450XL Series	PA-L5F	PA-L5F	PA-L5F	
3000, 3018/GZ, 3040/GZ, 3500, 3520/GZ, 3522/GZ, 3525GB, 3525GZ, 3545/GZ, 3550/GH, 3550GZ, 3610GZ Series	PA-L5F	PA-L5F	PA-L5F	
4000, 4010, 4012, 4012GZ, 4014/GB, 4016, 4024/GZ, 4025/GZ, 4026/GZ, 4028/GZ, 4028JP, 4030/GH, 4030GZ Series	PA-L5F	PA-L5F	PA-L5F	
4520/GZ, 4525/GZ, 4528/MX, 4530/GH, 4530GZ, 4532, 4534, 4535/GZ, 4536/GZ, 4538/GZ, 4540/GZ, 4541/BZ, 4542/GP, 4543/BZ Series	PA-L5F	PA-L5F	PA-L5F	
6000, 6010/GZ, 6018/GH, 6018GZ, 6018GX, 6020/GZ, 6021/GH, 6021GZ, 6022/GZ, 6023/GP, 6510/GZ, 6518/GZ, 6520/GZ, 6525/GP, 6530, 6531/GZ Series	PA-L5F	PA-L5F	PA-L5F	
7000, 7110/GX, 7210/GX, 7215/GX, 7300, 7305/GZ, 7305GX, 7310/MX, 7312/MX, 7320/GZ, 7322/GZ, 7324/GZ, 7325/GZ, 7326/GZ, 7330/GH, 7330GZ Series	PA-L5F	PA-L5F	PA-L5F	
7400, 7405/GH, 7405GX, 7410/GX, 7415/GX, 7422/GZ, 7422GZ, 7426/GX, 7430/JP, 7500, 7508/GX, 7510/GX Series	PA-L5F	PA-L5F	PA-L5F	
CX200, CX200S, CX200X, CX210, CX210S, CX210X, CX2600, CX2608, CX2610, CX2615, CX2618, CX2619, CX2620, CX2620h, CX2700, CX2720, CX2724, CX2724h, CX2726, CX2728 Series	PA-L5F	PA-L5F	PA-L5F	
M210, M210CS, M210E, M210S, M210X, M210XL, M250, M250E, M250ES, M250A, M250B, M250G, M250GS, M250X, M255-E, M255-E SB, M255 G, M280, M280E, M280Eb, M280GS, M285-E, M285-E SB, M285 G Series	PA-L5F	PA-L5F	PA-L5F	
M305, M305CRV, M320, M320CS, M320E, M320S, M320X, M320XL, M325, M325X, M360, M360S, M360SB, M360SE, M360X, M360XL, M360A, M360B, M360C Series	PA-L5F	PA-L5F	PA-L5F	
M405, M460A, M460B, M460E, M460E Plus, M460ES, M460S, M460SX, M460S-QS, M460SX Series	PA-L5F	PA-L5F	PA-L5F	
M500, M500B1, M505, M505B2 Series	PA-L5F	PA-L5F	PA-L5F	
ML3000, ML3704, ML3706, ML6000, ML6219, ML6701, ML6703, ML6704/H Series	PA-L5F	PA-L5F	PA-L5F	
MT3000, MT3400, MT3418, MT3700, MT3705, MT3707 Series	PA-L5F	PA-L5F	PA-L5F	
MT6400, MT6451, MT6452, MT6456, MT6700, MT6704/H, MT6705, MT6707, MT6800, MT6821, MT6828, MT6828H Series	PA-L5F	PA-L5F	PA-L5F	
MX3000, MX3042, MX3044/H, MX3200, MX3210, MX3212, MX3215, MX3225, MX3228/H, MX3258/H, MX3558/H, MX3560/H, MX3562, MX3563/H, MX3600, MX3610 Series	PA-L5F	PA-L5F	PA-L5F	
MX6000, MX6025/H, MX6027/H, MX6028, MX6030, MX6121, MX6123, MX6124/H, MX6128, MX6135, MX6420, MX6421, MX6423, MX6424/H, MX6425, MX6428, MX6430, MX6433/H, MX6436, MX6437, MX6438, MX6440/B, MX6440H, MX6441, MX6442, MX6450, MX6453, MX6455 Series	PA-L5F	PA-L5F	PA-L5F	
MX6625, MX6627/H, MX6628/H, MX6631, MX6633/H, MX6640/B, MX6641/H, MX6650/H, MX6708/H, MX6710, MX6750, MX6912, MX6951, MX6951H, MX6958, MX6960 Series	PA-L5F	PA-L5F	PA-L5F	
MX8500, MX8520, MX8523, MX8525, MX8528, MX8530, MX8554B, MX8556F, MX8700, MX8710, MX8711 Series	PA-L5F	PA-L5F	PA-L5F	
NX100X, NX200, NX200S, NX200X, NX210, NX250, NX250X, NX260, NX260X, NX500, NX500S, NX500X, NX510, NX510S, NX510X, NX550, NX550X, NX550XL, NX560, NX560X, NX560XL, NX570, NX570QS, NX570X, NX570XL Series	PA-L5F	PA-L5F	PA-L5F	
NX860, NX860X, NX860XL Series	PA-L5F	PA-L5F	PA-L5F	
S-7200, S-7200C, S-7200N Series	PA-L5F	PA-L5F	PA-L5F	
X2620H Series	PA-L5F	PA-L5F	PA-L5F	

Gateway Solo				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
1100, 1150, 1200, 1400, 1450 Series	PA-L5F	PA-L5F	PA-L5F	
2000, 2100, 2150, 2200, 2300, 2300LS, 2300XL, 2500/LS/SE/LX, 2550, 2551 Series	PA-L5F	PA-L5F	PA-L5F	
5000, 5100/XL, 5150LS, 5150SE, 5150XL, 5300/CS, 5300L, 5300LS, 5350 Series	PA-L5F	PA-L5F	PA-L5F	
9100, 9100LS, 9100SE, 9100XL, 9150, 9300, 9300CX, 9300VE, 9300XL Series	PA-L5F	PA-L5F	PA-L5F	

HP				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Envy 13, Envy 14, Envy 17	PA-N13	PA-N13	PA-N13	
Envy 15	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
G32, G42, G50, G60, G61, G62, G70, G71, G72 Series	PA-N13	PA-N13	PA-N13	
G3000, G5000, G6000, G7000	PA-N01	PA-N01	PA-N01	
HDX16	PA-N10	PA-N10	PA-N10	
HDX18, HDX9000	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
Mini 110, Mini 210, Mini 1000, Mini 1033, Mini 1100	PA-L42	PA-L42	PA-L42	
Mini 311	PA-N01	PA-N01	PA-N01	
2133 Mini-Note PC	PA-N10	PA-N10	PA-N10	
Mini 2140 Notebook PC	PA-N10	PA-N10	PA-N10	
Mini 5101, Mini 5102	PA-N13	PA-N13	PA-N13	
2533i Mobile Thin Client	PA-N10	PA-N10	PA-N10	
510, 530, 550 Notebook PC	PA-N10	PA-N10	PA-N10	
Slate 500	n/a	n/a	n/a	Adapter not available

HP EliteBook				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
2530p, 2540p, 2710p, 2730p Notebook PC	PA-N10	PA-N10	PA-N10	
6930p, 8530p, 8730w Notebook PC	PA-N10	PA-N10	PA-N10	

HP ProBook				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
ProBook 5310m	PA-N13	PA-N13	PA-N13	

HP / Compaq				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
2210, 2230s, 2510p, 2710p Notebook PC	PA-N10	PA-N10	PA-N10	
6000, 6510b, 6515b, 6530b, 6535b, 6710b, 6715b, 6720s	PA-N10	PA-N10	PA-N10	
6720i Mobile Thin Client	PA-N10	PA-N10	PA-N10	
6730b, 6730s, 6735b, 6735s, 6620s, 6830s, 6910p Notebook PC	PA-N10	PA-N10	PA-N10	
8510p, 8710p Notebook PC	PA-N10	PA-N10	PA-N10	
Mini CQ10, Mini 700	PA-L42	PA-L42	PA-L42	
Mini 2140 Notebook PC	PA-N10	PA-N10	PA-N10	
NC2400, NC4010, NC4200, NC4400 Notebook PC	PA-N10	PA-N10	PA-N10	
NC6120, NC6140, NC6220, NC6230, NC6320, NC6400 Notebook PC	PA-N10	PA-N10	PA-N10	
NC8430 Notebook PC	PA-N10	PA-N10	PA-N10	
NX6110, NX6115, NX6325, NX7300, NX7400, NX9420, NX9600 Notebook PC	PA-N10	PA-N10	PA-N10	
TC4200, TC4400 Tablet PC	PA-N10	PA-N10	PA-N10	

HP / Compaq TouchSmart				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
TouchSmart tx2-1000	PA-N13	PA-N13	PA-N13	
TouchSmart tx2-1100	PA-N13	PA-N13	PA-N13	
TouchSmart tx2-1300	PA-N13	PA-N13	PA-N13	

HP / Compaq Pavilion				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
DM1	PA-N13	PA-N13	PA-N13	
DM3	PA-N01	PA-N01	PA-N01	
DV1000, DV2000, DV4000, DV5000z, DV6000, DV8000 Series	PA-N01	PA-N01	PA-N01	
DV9000, DV9500 Series	PA-N01	PA-N01	PA-N01	
DV3, DV4, DV4t, DV4z, DV5, DV6, DV7 Series	PA-N10	PA-N10	PA-N10	
DV6i Quad, DV8	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
DV3100, DV3500, DV3600, DV3700 Series	PA-N13	PA-N13	PA-N13	
TX1000, TX1300, TX2000, TX2100, TX2500, TX2600 Series	PA-N01	PA-N01	PA-N01	
ZE2000, ZE4000, ZE4100, ZE4200, ZE4300, ZE4400, ZE4500, ZE4600, ZE4700, ZE4800, ZE4900, ZE5000 Series	PA-N01	PA-N01	PA-N01	
ZT3000, ZT3100, ZT3200, ZT3300, ZT3400 Series	PA-N01	PA-N01	PA-N01	
ZV6000, ZV6100, ZV6200 Series	n/a	n/a	n/a	Adapter not available.

HP / Compaq Presario				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
2100, 2200, 2500 Series	PA-N01	PA-N01	PA-N01	
A900, C300, C500, C700, F500, F700 Series	PA-N01	PA-N01	PA-N01	
CQ20, CQ32, CQ35, CQ40, CQ41, CQ42, CQ45, CQ50, CQ60, CQ61 Series	PA-N13	PA-N13	PA-N13	
CQ60, CQ61, CQ62, CQ70, CQ71, CQ72 Series	PA-N13	PA-N13	PA-N13	
F730, F750 Series	PA-N01	PA-N01	PA-N01	
M2000 Series	PA-N01	PA-N01	PA-N01	
NX9100 Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
R3000, R3100, R3200, R3300 Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
R4000, R4100, R4200 Series	n/a	n/a	n/a	Adapter not available.
V1000, V2000, V3000, V4000, V5000, V6000 Series	PA-N01	PA-N01	PA-N01	
V3700, V3800, V3900 Series	PA-N13	PA-N13	PA-N13	
X1000 Series	PA-N01	PA-N01	PA-N01	
X1200, X1300, X1400, X1500 Series	PA-N01	PA-N01	PA-N01	
X6000	n/a	n/a	n/a	Adapter not available.

HTC				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Shift X9500	PA-L5D	PA-L5D	PA-L5D	

Kohjinsha				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
SA series	PA-L5F	PA-L5F	PA-L5F	
SH series	PA-L5F	PA-L5F	PA-L5F	
SR series	PA-L5F	PA-L5F	PA-L5F	

Lenovo IdeaPad				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
S9, S9e Series	PA-SSF	PA-SSF	PA-SSF	
S10, S10e Series	PA-SSF	PA-SSF	PA-SSF	
S10-2 Series	PA-SSF	PA-SSF	PA-SSF	

Lenovo / IBM ThinkPad				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
A20m, A20p, A21e, A21m, A21p, A22e, A22m, A22p, A30, A30p, A31, A31p Series	PA-L5F	PA-L5F	PA-L5F	
R30, R31, R32, R40, R40e, R50, R50e, R50p, R51, R51e, R52 Series	PA-L5F	PA-L5F	PA-L5F	
R60, R60e, R61, R61i, R61e Series	PA-N09	PA-N09	PA-N09	
R400, R500 Series	PA-N09	PA-N09	PA-N09	
SL300, SL400, SL500 Series	PA-N09	PA-N09	PA-N09	
T20, T21, T22, T23, T30, T40, T40p, T41, T41p, T42, T42p, T43, T43p Series	PA-L5F	PA-L5F	PA-L5F	
T60, T60p, T61 Series	PA-N09	PA-N09	PA-N09	
T400, T500, W500 Series	PA-N09	PA-N09	PA-N09	
X20, X21, X22, X23, X24, X30, X31, X40, X41, X41 Tablet Series	PA-L5F	PA-L5F	PA-L5F	
X60, X60s, X61, X61s, X61s Series	PA-N09	PA-N09	PA-N09	
X200, X300 Series	PA-N09	PA-N09	PA-N09	
Z60, Z60m, Z60t, Z61p Series	PA-N09	PA-N09	PA-N09	

Lenovo / IBM 3000				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
C100, C200 Series	PA-N09	PA-N09	PA-N09	
N100, N200 Series	PA-N09	PA-N09	PA-N09	
V100, V200 Series	PA-N09	PA-N09	PA-N09	

Motion Computing				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
C5, F5, J3400	PA-L5F	PA-L5F	PA-L5F	
LE Series	PA-L5F	PA-L5F	PA-L5F	
LS Series	PA-L5F	PA-L5F	PA-L5F	
M Series	PA-L5F	PA-L5F	PA-L5F	

MSI				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Wind U100	PA-L5F	PA-L5F	PA-L5F	
L1350	PA-L5F	PA-L5F	PA-L5F	
CX600	PA-L5F	PA-L5F	PA-L5F	

Neoware				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
M100	PA-L5F	PA-L5F	PA-L5F	

OQO				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
Model 02	PA-CLA	PA-CLA	PA-CLA & MP3400-40	

Panasonic Toughbook				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
CF-08, CF-18, CF-19	PA-SSF	PA-SSF	PA-SSF	
CF-R3, CF-R4, CF-R4, CF-R5, CF-R6, CF-R7	PA-SSF	PA-SSF	PA-SSF	
CF-T1, CF-T2, CF-T4, CF-T5, CF-T7	PA-SSF	PA-SSF	PA-SSF	
CF-W2, CF-W4, CF-W5, CF-W7	PA-SSF	PA-SSF	PA-SSF	
CF-Y2, CF-Y4, CF-Y5, CF-Y7	PA-SSF	PA-SSF	PA-SSF	

Samsung				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
NC10, NC20 mini notebook Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
N110, N120, N130, N135, N148, N150 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
N210, N220, N310, N315, N510 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
NP-P200 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
P460, P560 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
Q1, Q1EX, Q1U Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
Q210, Q310, Q320 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
QX410-J01, QX410-S01 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
R410, R460, R505, R519, R520, R522, R560, R580, R610, R620, R700, R710, R720, R730, R780 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	
X120, X360, X420, X460, X520 Series	PA-L55	PA-L55	PA-L55 & PA-L55F	

Sony Vaio				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
PCG-700, PCG-800 Series	PA-L65	PA-L65	PA-L65	
PCG-F150, PCG-F160, PCG-F180, PCG-F190, PCG-F250, PCG-F270, PCG-F280, PCG-F290, PCG-F340, PCG-F350, PCG-F360, PCG-F370, PCG-F390 Series	PA-L65	PA-L65	PA-L65	
PCG-F430, PCG-F450, PCG-F480, PCG-F490, PCG-F520, PCG-F540, PCG-F560, PCG-F580, PCG-F590 Series	PA-L65	PA-L65	PA-L65	
PCG-F610, PCG-F630, PCG-F650, PCG-F680, PCG-F690 Series	PA-L65	PA-L65	PA-L65	
PCG-FX120, PCG-FX140, PCG-FX150, PCG-FX170 Series	PA-L65	PA-L65	PA-L65	
PCG-R505TS, PCG-R505TE, PCG-Z505LS, PCG-Z505LE, PCG-Z505JS, PCG-Z505JE, PCG-Z505HE, PCG-Z505HE Series	PA-L65	PA-L65	PA-L65	
PCG-XG9, PCG-XG18, PCG-XG19, PCG-XG28, PCG-XG29, PCG-XG38, PCG-XG39, PCG-XG500, PCG-XG700 Series	PA-L65	PA-L65	PA-L65	
UX180P	PA-L65	PA-L65	PA-L65	
VGN-AR290G	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
VGN-BX670, VGN-BX675 Series	PA-L65	PA-L65	PA-L65	
VGN-C140, VGN-C150, VGN-C190, VGN-C210, VGN-C220, VGN-C240, VGN-C250, VGN-C260, VGN-C290 Series	PA-L65	PA-L65	PA-L65	
VGN-CR240, VGN-290, VGN-CR305, VGN-CR390, VGN-CR490, VGN-CR590, VGN-CS190, VGN-CS290 Series	PA-L65	PA-L65	PA-L65	
VGN-FE550, VGN-FE570, VGN-FE590, VGN-FE600, VGN-FE650, VGN-FE660, VGN-FE670, VGN-FE680, VGN-FE690 Series	PA-L65	PA-L65	PA-L65	
VGN-FE770, VGN-FE780, VGN-FE790, VGN-FE855, VGN-FE870, VGN-FE880, VGN-FE890 Series	PA-L65	PA-L65	PA-L65	
VGN-FS500, VGN-FS520, VGN-FS530, VGN-FS540, VGN-FS550, VGN-FS550, VGN-FS570 Series	PA-L65	PA-L65	PA-L65	
VGN-FS620, VGN-FS630, VGN-FS640, VGN-FS650, VGN-FS660, VGN-FS670, VGN-FS680, VGN-FS690 Series	PA-L65	PA-L65	PA-L65	
VGN-FS710, VGN-FS720, VGN-FS730, VGN-FS740, VGN-FS750, VGN-FS760, VGN-FS770, VGN-FS780, VGN-FS790 Series	PA-L65	PA-L65	PA-L65	
VGN-FS810, VGN-FS830, VGN-FS840, VGN-FS850, VGN-FS875, VGN-FS900 Series	PA-L65	PA-L65	PA-L65	
VGN-FS920, VGN-FS940, VGN-FS950, VGN-FS960, VGN-FS970, VGN-FS980, VGN-FS990 Series	PA-L65	PA-L65	PA-L65	
VGN-FW290 Series	PA-L65	PA-L65	PA-L65	
VGN-FZ130, VGN-FZ140, VGN-FZ150, VGN-FZ160, VGN-FZ180, VGN-FZ190 Series	PA-L65	PA-L65	PA-L65	
VGN-N110, VGN-N120, VGN-N130, VGN-N150, VGN-N160, VGN-N170, VGN-N220, VGN-N230, VGN-N250, VGN-N270, VGN-N320, VGN-N330, VGN-N370 Series	PA-L65	PA-L65	PA-L65	
VGN-NS190, VGN-NS235, VGN-NS290 Series	PA-L65	PA-L65	PA-L65	
VGN-P530H, VGN-P588E, VGN-P598E Series	PA-L47	PA-L47	PA-L47	
VGN-S380, VGN-S430, VGN-S460, VGN-S470, VGN-S480, VGN-S550, VGN-S560, VGN-S570, VGN-S580, VGN-S660 Series	PA-L65	PA-L65	PA-L65	
VGN-SR290 Series	PA-L65	PA-L65	PA-L65	
VGN-SZ210, VGN-SZ220, VGN-SZ230, VGN-SZ240, VGN-SZ250, VGN-SZ260, VGN-SZ270, VGN-SZ280 Series	PA-L65	PA-L65	PA-L65	
VGN-SZ320, VGN-SZ330, VGN-SZ340, VGN-SZ360, VGN-SZ370, VGN-SZ380, VGN-SZ390 Series	PA-L65	PA-L65	PA-L65	
VGN-SZ430, VGN-SZ440, VGN-SZ450, VGN-SZ460, VGN-SZ470, VGN-SZ480, VGN-SZ491, VGN-SZ640, VGN-SZ650, VGN-SZ670 Series	PA-L65	PA-L65	PA-L65	
VGN-SZ691, VGN-SZ750, VGN-SZ770, VGN-SZ791 Series	PA-L65	PA-L65	PA-L65	
VGN-TXN25NB Series	PA-L65	PA-L65	PA-L65	

Toshiba Mini Notebook				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
NB205-N2xx, NB205-N3xx	PA-L5F	PA-L5F	PA-L5F	
NB305-N3xx, NB305-N4xx	PA-L5F	PA-L5F	PA-L5F	

Toshiba Portege				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
2000, 2010, 3500, 3505, 4000, 4005, 4010 Series	PA-L63	PA-L63	PA-L63	
7000CT, 7010CT, 7020CT, 7140CT, 7200CT/Cte, 7220Cte Series	PA-L63	PA-L63	PA-L63	
M100, M200, M205, M300, M400, M405, M700, M705, M750 Series	PA-L63	PA-L63	PA-L63	
R100, R200, R400, R500, S100 Series	PA-L63	PA-L63	PA-L63	

Toshiba Qosmio				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
E15, F15, F25, F45 Series	PA-L63	PA-L63	PA-L63	
G15, G25, G35, G45 Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
X305	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.

Toshiba Satellite				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
1400, 1405, 1410, 1415, 1800, 1805 Series	PA-L63	PA-L63	PA-L63	
2060, 2100, 2140XCDs, 2180CDT, 2210CDT/XCDS, 2230, 2250, 2400, 2405, 2410, 2415 Series	PA-L63	PA-L63	PA-L63	
2505CDS, 2510, 2520, 2530, 2540, 2550, 2590CDT/CDS/CDT/XDVD, 2610, 2615DVD, 2650, 2655XDVD, 2670, 2710, 2740, 2750, 2770, 2800/2805 Series	PA-L63	PA-L63	PA-L63	
3000, 3005 Series	PA-L63	PA-L63	PA-L63	
4000CDS/CDT, 4005CDS/CDT, 4010CDS/CDT, 4015CDS/CDT, 4020CDT, 4025CDT, 4030CDT, 4060, 4070, 4080CDT, 4090XDVD, 4100XDVD Series	PA-L63	PA-L63	PA-L63	
5000, 5005, 5105, 5200, 5205 Series	PA-L63	PA-L63	PA-L63	
A10, A15, A30, A35, A50, A55, A60, A65, A70, A75, A80, A85 Series	PA-L63	PA-L63	PA-L63	
A20, A25, A40, A45 Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
A100, A105, A110, A130, A135 Series	PA-L63	PA-L63	PA-L63	
A200, A205, A215 Series	PA-L63	PA-L63	PA-L63	
L10, L15, L20, L25, L35, L45 Series	PA-L63	PA-L63	PA-L63	
M20, M30, M35, M40, M45, M50, M55, M60, M65 Series	PA-L63	PA-L63	PA-L63	
M100, M105, M110, M115 Series	PA-L63	PA-L63	PA-L63	
M200, M205 Series	PA-L63	PA-L63	PA-L63	
P10, P15, P30, P35 Series	PA-L63	PA-L63	PA-L63	
P100, P105 Series	PA-L63	PA-L63	PA-L63	
P100-S19xxx, P105-S921, P105-S9xxx Series	n/a	n/a	n/a	Laptop power requirement exceeds battery current output.
P200, P205 Series	PA-L63	PA-L63	PA-L63	
R10, R15, R20, R25 Series	PA-L63	PA-L63	PA-L63	
U200, U205 Series	PA-L63	PA-L63	PA-L63	
U300, U305 Series	PA-L63	PA-L63	PA-L63	

Toshiba Satellite Pro				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
430, 440, 450, 460, 470, 480, 490 Series	PA-L63	PA-L63	PA-L63	
4280ZDVD, 4220, 4260DVD, 4280XDVD, 4300, 4600 Series	PA-L63	PA-L63	PA-L63	
6000, 6100 Series	PA-L63	PA-L63	PA-L63	
A200, A210 Series	PA-L63	PA-L63	PA-L63	
M10, M15 Series	PA-L63	PA-L63	PA-L63	
S300, S300M Series	PA-L63	PA-L63	PA-L63	

Toshiba Tecra				
Model	MP3450 / MP3450 R2	MP3450i / MP3450i R2	MP3750 / MP3750 R2	Additional Information
8000, 8100, 8200, 9000, 9100 Series	PA-L63	PA-L63	PA-L63	
A1, A2, A3, A4, A5, A8, A9, A10 Series	PA-L63	PA-L63	PA-L63	
M1, M2, M2V, M3, M4, M5, M6, M7, M8, M9, M10 Series	PA-L63	PA-L63	PA-L63	
R10, S1, S2, S3 Series	PA-L63	PA-L63	PA-L63	
TE2000, TE2100, TE2300 Series	PA-L63	PA-L63	PA-L63	