

## iPad & Tablets

Green Text with Light Green Background indicates the adapter tip is included with product.

Red Text with Clear Background indicates the adapter tip is sold separately.

N/A indicates that the adapter is not available or the product is not compatible.

\* MP3450i R2 requires PA-L34 or PA-S34 (not included in original package) to use UA-xxx adapter tips through DC Out Port.

### Acer

Model	MP3450	MP3450 R2	MP3450i R2*	MP3750	MP3750 R2	Additional Information
Iconia A500	PA-L30	PA-L30	PA-L30	PA-L30	PA-L30	

### Amazon

Model	MP3450	MP3450 R2	MP3450i R2	MP3750	MP3750 R2	Additional Information
Kindle Fire	UA-U11	UA-U11	UA-U11	UA-U11	UA-U11	

### Apple

Model	MP3450	MP3450 R2	MP3450i R2*	MP3750	MP3750 R2	Additional Information
iPad, iPad 2	PA-USB2	iPod USB Cable	iPod USB Cable	PA-USB2	iPod USB Cable	**MP3300-16 can be used to charge through DC Out port at 2.1A (MP3450, MP3450i only)

### Archos

Model	MP3450	MP3450 R2	MP3450i R2*	MP3750	MP3750 R2	Additional Information
Archos 28, 32, 43, 48, 70, 101	Archos USB Cable	Archos USB Cable	Archos USB Cable	Archos USB Cable	Archos USB Cable	Archos USB Cable will need to be used
Archos 80 G9, 101 G9	Archos USB Cable	Archos USB Cable	Archos USB Cable	Archos USB Cable	Archos USB Cable	Archos USB Cable will need to be used

### ASUS

Model	MP3450	MP3450 R2	MP3450i R2*	MP3750	MP3750 R2	Additional Information
Eee Pad Transformer-TF101	MP3300-16	MP3300-16	MP3300-16	MP3300-16	MP3300-16	ASUS USB Cable will need to be used

### Blackberry

Model	MP3450	MP3450 R2	MP3450i R2	MP3750	MP3750 R2	Additional Information
PlayBook	UA-U11	UA-U11	UA-U11	UA-U11	UA-U11	

### HTC

Model	MP3450	MP3450 R2	MP3450i R2	MP3750	MP3750 R2	Additional Information
Evo View 4G	UA-U11	UA-U11	UA-U11	UA-U11	UA-U11	HTC Evo USB Cable can be used with USB port
Flyer	UA-U11	UA-U11	UA-U11	UA-U11	UA-U11	HTC Flyer USB Cable can be used with USB port

### Motorola

Model	MP3450	MP3450 R2	MP3450i R2	MP3750	MP3750 R2	Additional Information
XOOM	UA-NOK 2	UA-NOK 2	UA-NOK 2 & PA-S34	UA-NOK 2 & PA-S34	UA-NOK 2 & PA-S34	

### Samsung

Model	MP3450	MP3450 R2	MP3450i R2	MP3750	MP3750 R2	Additional Information
Galaxy Tab	MP3300-16	Galaxy Tab USB Cable	Galaxy Tab USB Cable	NA	Galaxy Tab USB Cable	Samsung Galaxy Tab USB Cable can be used with USB port